



ENGLISH

INSTRUCTION MANUAL

MD250



MD250

CE

• MINI DEHUMIDIFIER



Filter removal



IMPORTANT SAFETY INSTRUCTIONS

Before any installation, use and maintenance operation, read the safety instructions in this manual carefully.

Remove all packaging materials from the unit, keep it away from babies and small children to avoid the danger of suffocation.

Before inserting the plug make sure that the voltage is within the range indicated on the rating label on the adapter.

The MD250 is intended exclusively for the use for which it was created, Amcor is not responsible for any damage caused by improper use.

The MD250 is safe. However, as with other electrical appliances, use it with care.

Do not clean the MD250 by spraying it or immersing it in water.

Disconnect the product from the electrical outlet before cleaning the unit or its components.

Do not connect the MD250 to an electrical outlet using an extension cord. If there is no accessible outlet, a licensed electrician should install one.

When not in use, store out of reach of children.

Warning

Any service, other than regular cleaning should be performed by an authorised service representative. Failure to do so could result in loss of warranty.

If the supply cord becomes damaged, it must be replaced by the manufacturer or by its service agent or similarly qualified person in order to avoid a hazard. Use only the supplied adapter.

POSITIONING

Ideal for small bedroom, wardrobe, storage, cloaks or shoe cupboard – wherever you may want to keep dry or remove local dampness.

Danger

Do not use this unit in a bathroom or shower. Do not drip water onto the adapter or dehumidifier.

Ensure that the filter and front vents are clean and not obstructed so air can circulate freely through the unit.

HOW IT WORKS

Simple explanation of the Peltier effect (see picture on page 11).

Current passing through two dissimilar metals or semiconductors that are connected to each other at two junctions creates a heat difference between these junctions. In other words: one junction cools off while the other heats up.

The cold side is used to condensate the moisture from the air in the MD250 dehumidifier.

A Peltier device has no moving parts making it very reliable and silent.

OPERATION

- Ensure the MD250 is OFF (**O**) when connecting the power cord of the adapter.
- Press the button to ON (**I**), the green LED is on when in operation.
- The unit will switch off automatically and the red LED illuminate when the water tank is full.

Emptying the water tank

- First turn off the MD250 (**O**).
- Hold the top of the unit, then remove the water tank.
- Turn the plug and empty the water tank.
- Fix the plug and place the water tank back into the unit.
- To continue dehumidifying, press the button to ON (**I**) again.

CLEANING

Before cleaning, first turn off and unplug from the mains socket.

Housing

Use a damp soft cloth to clean off any dust and stains on the unit. Do not use petrol, benzene, or any chemicals to clean the unit as this will result in damaging the surface.

Danger: do not allow any water to drip onto internal parts.

Filter

Remove the filter from the unit; clean in lukewarm water then dry thoroughly. Never operate the MD250 without filter.


TROUBLESHOOTING

If your MD250 does not operate or is not dehumidifying, please check the following:

- the power cord is connected and the socket is switched on.
- the vents are not blocked and the filter is clean.

Technical information can be found on page 11.

TECHNISCH	TECHNIQUE	TECHNISCH	TECHNICAL	
Adapter	Adaptateur	Adapter	Adapter	220 - 240 V AC -> DC 12 V
Energieverbruik	Consommation d'énergie	Energieverbrauch	Power consumption	40 W ± 5%
Ontvochtiging (bij 30 °C en 80% RV)	Déshumidification (à 30 °C et 80% HR)	Entfeuchtung (bei 30 °C und 80% rF)	Moisture removal (at 30 °C and 80% RH)	250 ml /24h
Watertank	Réservoir à eau	Wasserbehälter	Tank capacity	500 ml
Gewicht	Poids	Gewicht	Weight	0,98 kg



VERWIJDEREN

HORS SERVICE

AUSSERBETRIEBSTELLUNG


DECOMMISSIONING

Niet vergeten:

Afgedankte elektrische producten mogen niet bij het gewone huisvuil worden gezet. Breng dit product naar uw plaatselijke milieustraat zodat het op de juiste wijze wordt behandeld.

Ne pas oublier:

Les déchets d'équipements électriques et électroniques ne doivent pas être jetés avec les déchets domestiques. Ce produit doit être déposé dans votre déchetterie communale pour un traitement spécifique.



Nicht vergessen:

Elektro- und Elektronikaltgeräten sollen nicht als unsortierten Siedlungsabfall beseitigt werden. Dieses Produkt muss zur Entsorgung an Ihren Wertstoffhof abgeliefert werden.

Reminder:

Waste electrical products must not be disposed of with household waste.
This product should be taken to your local recycling centre for safe treatment.

