

SPA Accessories



1.

Temperature sensor

Temperature sensor TF104
to measure the cabin temperature

Vandalism protection
in high quality stainless steel design
to protect the temperature sensor TF104

Temperature sensor FTF
optional with safety temperature monitor
when the maximum temperature is
accomplished it shuts off



2.

Steam inlet

Steam bath nozzle made of stainless steel
with plastic protection cowling for
protected steam insertion into the cabin

Fog maker (mixing tube)
for mixing steam and fresh air together
giving a denser feel, also reduces the
steam entry temperature

Reducing kit
DN40 to DN25

Steam hose
DN40 and DN25



3.

Air in / outlet

Duct slide-in fan
230 V, optional 24 V for inlet
or outlet air via 100 HT mm duct pipe

Rotary potentiometer
for 24 V
for steam bath fan control



4.

Control

Remote control*
for the comfortable handling in-
and outside the cabin

Relay circuit board for the capacity expansion
for (inlet / outlet) fans, essence injector,
light etc.

Time relay
Steam production via push button –
do-it-yourself shutdown

Clock timer
for the setting of usage periods
alternatively please seek information of
our remote control timer function



* Only available for HeaterSlim

5.

Essence

Essence pump
in 24V / 230V with or without en suite timer
and injection calibration available

Essence non-return valve
for a save essence feed in into the cabin
steam without drainage of the inlet pipe

Exhaust filter for the essence container
for the optimal and non-clogging
clearance of the essence container

T-piece from stainless steel
for essence feed or condensate discharge

